


# SK-029W Remote Cable Assembly Installation Instructions

When using the SK-029W, Format 34 as a remote reader to the 28SA Plus, use this cable to connect the SK-029W to the Wiegand Input J2 on the 28SA Plus main board.



This cable may be extended up to 500' by splicing in additional wire. Note that the Data 1 uses the White wire at position #1.

## **WARNING:**

**Always disconnect power to the 28SA Plus before connecting the remote reader cable.**